

AME Shelf-Support Nut Replacement

1. Put the mirror cabinet flat and look for the groove on the side of the cabinet. (It can be done while installed, yet, it requires extra focus, not to lose the nut, as it may easily fall during the work.)



2. Put the nut in the slot of the cabinet, and push it in as deep as you reach.



3. Take over the nut from inside, using a pen, or any narrow object, move it up to a suitable position, and then lock the glass clamp.

