

TILE FLANGE INSTALLATION INSTRUCTION



READ ALL INSTRUCTIONS BEFORE UNPACKING THE PRODUCT

BEFORE YOU BEGIN

This Tile Flange is intended to fill the gap between the bath rim and the finished wall material on apronless bath installations. You must apply a continuous bead of high quality silicone sealant, as illustrated, to obtain a watertight seal.

There is enough Tile Flange supplied for any Fine Fixtures apronless bath. Some cutting will be required. The installation kit contains a Tile Flange and a length of pressure-sensitive tape.

Apply the Tile Flange to the bath rim before installing the bath.



Risk of improper installation.
Do not apply the Tile Flange or pressure-sensitive tape
in temperatures below 40° F (4° C) .



INSTALLATION

Thoroughly Clean the bath rim. Temporarily position the Vinyl bead around the bath rim as illustrated. Trim excess tape material from the bath corner areas to form a miter joint. **Do not cut totally through the bead when mitering the corners. Some tiling beads may require trimming of the bottom edge for proper fit.**

Apply the length of pressure-sensitive tape to the bath rim 3/4" (1.9cm) in from the rim edge. Use the bottom edge of the rim as a guide. Do not remove the paper backing at this time. Cut away any excess pressure-sensitive tape from the corners to form a miter joint. Remove the paper backing.

Start the Tile Flange 3/4" (1.9cm) in from the end of the rim. Position the Tile Flange properly on the bath, as illustrated. Press the Tile Flange firmly against the pressure-sensitive tape. Repeat the procedure while working toward the opposite end of the bath.

When the Tile Flange is in place, firmly press the Tile Flange in place with the heel of your hand to ensure proper adhesion.

The bath is now ready for installation, leveling, framing, and the application of wall materials. Apply a continuous bead of high-quality silicone sealant between the bath rim and the edge of the finished wall. The silicone sealant must completely cover the Vinyl bead to ensure a watertight seal. Wipe away any excess sealant, and fill any voids.

